

50 mm

Brick up hole using reclaimed imperial size bricks selected for matching colour, with good quality arises. Flush pointing. Point up roof verge.

Allow to protect adjacent roof and make good any damaged slates on completion.

Repointing.

Repoint where chimney removed  
Repoint verge.

Form lead shoot outlet thru. brick wall into new cast iron hopper, with new cast iron rwp to discharge onto lower roof.

Line underside of first floor to alley between any brick arches using supalux board to provide 1 hour fire protection. Batten out beneath and finish with sw t+g boarding, paint finish.

see dwg. CXX for gates.

Fan assisted balanced flue.

# SIDE ELEVATION