

- All dimensions and levels are to be checked on site.
- Any discrepancies are to be reported to the architect before any work commences.
- This drawing shall not be scaled to ascertain any dimensions. Work to figured data only.
- This drawing shall not be reproduced without express written permission from AEMV.
- The overall drawings and ownership boundaries are produced using all reasonable endeavours. AEMV cannot be responsible for the accuracy or scale discrepancy of base plans supplied to them.

